

The image shows the cover of a manual for a professional mandoline slicer. The background is a vibrant yellow. In the upper right corner, there is a logo for 'MIU' with 'F. NEUBER' written in smaller text below it. The central part of the cover features a close-up photograph of the mandoline's metal frame and a white plastic cutting plate. A black handle is visible on the left side of the frame. In the background of the photo, a slice of orange is visible. The overall design is clean and professional.

MIU
F. NEUBER

**Professional
Mandoline
Manual**

Model: 90737

Introduction

Your MIU France Stainless Steel Mandoline features a selection of blades with variable thickness adjustments which make it one of the most versatile kitchen tools available for slicing and cutting vegetable and fruits. By switching blades and adjusting the thickness of each cut, this Mandoline can produce various cut styles including French fry, julienne, paper-thin, crinkle, and waffle cuts.

Warning: Blades are extremely sharp. Always use the included safety holder / pusher and please read all instructions and use with care and caution. Always hold the hand grip on top of the Mandoline when processing food. Use extreme caution when handling blades as they are very sharp. Never store your blades loose in a drawer or on the countertop. Always use the included plastic storage holder. Do not attempt to use this Mandoline until you have carefully studied and understand these instructions. Failure to do so may result in injury to yourself or the Mandoline.

All metal parts of the Mandoline are made up of high quality 18/10 stainless steel, making the Mandoline completely dishwasher safe. The straight carbon blade is for slicing while the serrated blade is mainly used for crinkle or waffle cuts. The julienne blades can create vegetable or fruit sticks of various widths. The stainless steel guiding plate located on the upper section of the Mandoline is for adjusting the thickness of the vegetable or fruit slices. Finally, the safety holder / pusher protects your hands from the blade. For use on the kitchen counter, unfold both the upper and lower legs. When you want to use the Mandoline directly on a container such as mixing bowl, the Mandoline should lay flat across the container, but please remember not to fold the upper leg.

Note: For best results, vegetables should be pre-cut into manageable chunks in order to properly fit within the safety holder.

Before Your First Use

Carefully unpack your Mandoline and wash thoroughly according to the Care and Cleaning section of this manual.





Table of Contents

Introduction	1
Before Your First Use	2
Know Your Mandoline	5
Assembling Your Mandoline	6
Using Your Mandoline	7
Care and Cleaning	9
Blade Storage	9
Limited Warranty	10
Parts Ordering	10



Know Your Mandoline



Assembling Your Mandoline



1. Unfold the legs as shown in figure 1. Insert the blade of choice according to the section “Using your Mandoline”
2. Place food to be processed onto the safety holder spikes and using the black plastic holder/pusher with downward pressure move back and forth across the blades to process food, figure 2



Using Your Mandoline



Figure 4

Adjusting the Thickness

You can adjust the thickness of a given cut by moving the lever beneath the gliding plate in a downward arc for thinner slices, and in an upward arc for thicker slices (figure 3). When holding the Mandoline and looking down the top of the gliding plate, the gap between the upper plate and the blade is actually the thickness of the cut. (figure 4) The incorporation of a thickness adjustment lever allows you to adjust the lever to any desired position within its arc and the thickness will stay the same during slicing. Applying firm pressure should not change the thickness.



Figure 5

Inserting Blades

Warning: Please hold blades by their handle to prevent accidental injury.



Figure 6

Straight Blade (Slicing)

The straight blade (figure 5) must be inserted from the side of the Mandoline in the horizontal slot, (figure 6). It is ideal for slicing a variety of foods, such as carrots, cabbage, lemons, and potatoes, just to name a few. Your imagination is the limit. However, the blades works best on firm vegetables and fruits. Overly soft vegetables and fruits will tend to tear, rather than slice cleanly. The straight blade is especially useful to make paper thin slices. It must be use in conjunction with a julienne blade to create julienne cuts.



Figure 7

Using Your Mandoline cont'd



Figure 8

Serrated Blade (Crinkle & Waffle Cuts)

The serrated blade (figure 7) must be inserted from the side of the Mandoline in the horizontal position (figure 6). It is ideal for crinkle and waffle cuts. A crinkle cut requires only one pass over the blade. For waffle cuts, you have to adjust the height of the upper plate so that the slices you are creating are very thin. First, you make one slicing pass with the serrated blade. Next, you rotate the safety holder/pusher 90 degrees, and make a second pass over the serrated blade to complete the waffle cuts.

Note: The serrated blade should not be used in conjunction with julienne blades, because the blades may interfere with each other.



Figure 9

The Julienne Blades

The julienne blades (figure 8) must be inserted on the opposite side of the straight blade in the vertical position (figure 9). You should only use the julienne blade in conjunction with a straight slicing blade (figure 5). Always hold the julienne blades by their handle. They are ideal for making sticks, fries and shoestring potatoes. These blades are to be inserted into the side of (i.e. body) opposite the side that the straight and serrated blades are inserted into (figure 6). Insert the desired width julienne blade and be sure to insert it all the way into the slot, seating firmly. Adjust the thickness of the upper plate and then place the vegetable lengthwise into the safety handle. Use firm and even pressure to slide the safety holder/pusher from the upper glide plate down to the lower glide plate. Avoid undue force, as the glide plate can be forced down, changing the thickness of the cut.



Care and Cleaning

The Stainless Steel Mandoline is designed to require only minimal maintenance. The body and the blades are dishwasher safe, but hand washing is always preferred to extend product life. The slicing blade should be sharpened from time to time, while the serrated blade should be brought to a cutlery specialist for occasional sharpening services. Any good gourmet store should be able to give a recommendation. For storage, place Mandoline in a clean, dry location.

Warning! Always remove blades from the Mandoline before attempting to clean to prevent laceration.

It is recommended to wash the Mandoline in hot water before use. It should also be washed after every use, with hold soapy water in the sink or in the dishwasher. Rinse with hot water in order to flush out vegetable residues. You may then towel and/or air dry. Do not clean the Mandoline with any implement which might damage the edge of the blades. The Mandoline does not require any lubricating greases or oils. Lubricants that are unsafe for human consumption should not be applied.

Blade Storage



Figure 10 The straight ,serrated and julienne blades should be stored in the plastic holder as shown in figure 10.

Limited Warranty

This warranty covers all defects in workmanship or materials in the mechanical parts, arising under normal usage and care, in this product for a period of 12 months from the date of purchase provided you are able to present a valid proof of purchase. A valid proof of purchase is a receipt specifying item, date purchased, and cost of item. A gift receipt with date of purchase and item is also an acceptable proof of purchase. Product is intended for household use only. Any commercial use voids the warranty.

This warranty covers the original retail purchaser or gift recipient. During the applicable warranty period within normal household use, we will repair or replace, at our discretion, any mechanical part which proves defective, or replace unit with a comparable model.

To obtain service under the terms of this warranty, call our customer service at: (206) 605-0555

THIS LIMITED WARRANTY COVERS UNITS PURCHASED AND USED WITHIN THE UNITED STATES AND DOES NOT COVER:

- Damages from improper installation
- Defects other than manufacturing defects
- Damages from misuse, abuse, accident, alteration, lack of proper care and maintenance
- Damage from service by other than an authorized dealer or service center.

This warranty gives you special legal rights and you may also have other rights to which you are entitled which may vary from state to state.

Replacement Parts

Replacement parts are available for purchase. Please check our website for up to date parts list and prices. <http://www.miufrance.com/parts.htm>



IMPORTANT NOTICE

If you have any problems with this unit, contact Consumer Relations for service.

Email: customerservice@miufrance.com

Please read operating instructions before using this product.

Please keep original box and packing materials in the event that service is required.

Contents and designs are subject to change without notice.



MIU France

(206) 605-0555

Email : customerservice@miufrance.com

Website: <http://www.miufrance.com>

Model: 90737

Made in China with exact specification from MIU France

MIU France is a registered trademark of MIU, LLC